



## CARE & MAINTENANCE - ULTRAGLAZE ACRYLIC

Our advice is to not immediately remove the protective film on your ULTRAGLAZE Acrylic cabinets. The film should only be removed once you have read the maintenance instructions listed below and only after all other site trade work has been completed.

### CLEANING KIT

You have been supplied a complimentary cleaning kit with your ULTRAGLAZE Acrylic cabinets. The kit contains a Microfibre cleaning cloth and a bottle of VuPlex nonabrasive cleaner. We recommend the use of Vuplex and a Micro Fibre cloth for cleaning. Or a micro Fibre cloth with warm water. New bottles of Vuplex can be purchased through our online store found at [www.peterhay.co.nz](http://www.peterhay.co.nz).

### ULTRAGLAZE ACRYLIC SURFACE

Your ULTRAGLAZE Acrylic doors and panels come with a protective film. Once this film is removed it will initiate the curing process. It takes up to 48 hours for the surface to be completely cured. For this reason we recommend that upon removal of the protective film, lightly spray your doors and panels with Vuplex. Then using the Microfibre cloth, wipe the surface using a light circular motion. This will remove any residue left from the protective film, and also help the curing process.

For the first 48hours do not clean the surface after the initial cleaning.

### CLEANING AND MAINTENANCE OF ULTRAGLAZE ACRYLIC

Never use any cleaning products which are (or contain): alcohol based, solvent based, abrasive cleaners, acetone, paraffin, petrol, pinewood or oils, glass cleaner. These chemicals can damage the ULTRAGLAZE Acrylic surface.

Thank you for purchasing from our ULTRAGLAZE Acrylic range. We hope you enjoy your cabinets for many years to come.

FOR MORE INFORMATION VISIT [www.ultraglaze.co.nz](http://www.ultraglaze.co.nz)